

Hydraulic Breakers JTHB SERIES

Hydraulic Breakers

Hydraulic breakers from 90-4,550kg a range of 14 breakers

One Blow, its shattered! Proven track record, KOMATSU offers guarantee for JTHB Breakers.



JTHB SERIES

Walk-Around

Komatsu's JTHB breakers deliver exceptional impact energy, long life with low operating costs. What's more, they minimize operator fatigue and environmental impact.

These unique benefits are all due to an innovative blend of a simple yet efficient design and advanced 'accumulator-free' technology.

With a complete range of 14 breakers all based on the same design philosophy, JTHB breakers are ideal for applications from construction and demolition to recycling, mining and quarrying.

Innovative features, real benefits



partner



Komatsu Chisel

Туре	Purpose & Application			
Flat	General Demolition through cutting action – Penetration breaking e.g. trenching and slope finishing			
Moil Point	General Demolition – Penetration Breaking e.g. concrete, rock bed			
Flat End	Demolition – Impact Breaking e.g. secondary rock breaking, scaling in mines and tunnels, reinforced concrete floors			



Specially hardened alloy

increases durability and range of applications

Komatsu Advantage

Automatic Oil Flow Change

With Komatsu excavator, possible to change hydraulic oil flow for breaker by screen monitor in cabin. It is also possible to switch the hydraulic circuit between Breaker and Attachment mode by that monitor. (after PC200-7 onwards)



KOMATSU Recommended Hydraulic oil High-perfomance hydraulic oils that have passed Komatsu's unique stringent quality requirements



KOMATSU Recommended **Hyper White grease**

Extreme-pressure grease suited even for high load construction machinery

Major features

Product name		Antiwear	Heat resistance	Water resistance	Anticorrosion	Remarks
Hyper white grease	0	0	0	0	0	Multipurpose white grease
LithiumnEP grease		0	0	0	0	General grease

Do not use Molybdenum content grease It will cause the hydraulic components to fail on excavator.



All 14 Models Line-up







Model Type		JTHB08-3	JTHB10-3	JTHB20-3	JTHB30-3	JTHB40-3	JTHB50-3 / JTHB50-3(BHL)
Working weight							
Side Mount Bracket	kg	_	85	105	175	235	300
Top Mount Box Bracket	kg	85	125	170	250	340	400
Oil flow	ℓ/min	18~25	20~30	20~35	25~45	30~55	35~60
Operating pressure	MPa	6~13	7~14	8~15	10~15	10~16	10~16
Impact rate	bpm	930~1300	700~1200	600~1150	550~1000	580~1060	550~1000
Chisel diameter	mm	φ 40	φ 4 5	φ 50	ϕ 58	φ 64	φ 75
Chisel weight	kg	4.0	5.5	7.4	11.9	15.2	23.2
Hose size	inch	3/8	1/2	1/2	1/2	1/2	1/2
Gas pressure	MPa	0.8	0.8	0.8	0.8	0.8	0.8
Base machine	Ton	0.7~1.5	1~2	1.5~2.5	2.4~4	3~4.5	3.8~6
Excavator model		PC10MR	PC18MR	PC20MR	PC30MR/PC35MR	PC45MR	PC55MR/56/WB9X






JTHB60-3	JTHB120-3	JTHB160-3	JTHB210-3	JTHB350-3	JTHB450-3	JTHB650-3 ** intro. in 2015
430	820	1010	1710	2530	3100	4550
585	950	1240	1780	2790	3600	4550
45~80	80~120	100~140	160~200	180~230	240~300	280~390
10~16	14~18	12~17	14~18	13~18	14~18	14~18
550~1000	450~720	430~600	450~630	350~450	340~470	370~470
φ 95	φ 105	φ 115	φ 135	φ 146	φ 160	φ 178
42.6	63.5	91.5	133	185	236	
3/4	3/4	3/4	1"	1"	1-1/4	1-1/4
1	1.1	0.8	1.1	0.8	0.8	0.8
6~11	8~14	14~20	18~25	27~40	38~50	45~70
PC60/88/78US	PC128US/138US/100/120	PC160/180/PW200	PC200/270	PC300 class	PC400 class	PC600 class

Precautions for Hydraulic Breaker

Maintenance

1 Greasing every 2 hours, chisel must be pushed-in position





into oil, seal damage,

model	Grease pump
JTHB08~20	2~3
JTHB30∼40	4~5
JTHB50∼60	5∼6
JTHB120	6~7
JTHB160~210	7~8
JTHB350	8~9
JTHB450	9~10
JTHB650	10~11

2 Filter Elements, Hydraulic Oil, Consumable Parts.









Komatsu Filter: every 250hours (Main/Additional) Komatsu Oil: Every 1000 hours Use only genuine filter and oil. (PC120-7 up)

3 Before Operation




Other modes may cause damage to Breaker/Excavator

Breaker seal recovery







Operate Breaker under temperature ranging from 40 to 60 degrees

4 Storage



Main hydraulic circuit on Breaker-mode Oil & Filter Replacement Cycle (in case of 100% breaker use) Replace Hours (PC200-8 with Hydraulic Oil 1000 Hydraulic Oil Filter Element 250 Pilot Filter Element 250 Additional Filter for Breaker 250

Operation

1 Stop operation when hose swings irregularly




water/mud It causes damage to Breaker and Excavator.

Chisel bush NOT into Do Not operate by stroke end position

JTHB SERIES


4 Keep 90 degrees angle to object



No more than 1 minute continuous hammering



It causes damage to Work equipment, 6 Break from end edge for large and hard rock



Stop hammering when object is broken



10 Do NOT swipe with

It causes damage to Breaker and

breaker

Excavator.

8 Do NOT jiggle by chisel



It causes damage to Breaker and Excavator.



11 Do NOT move rocks



12 Do NOT lift objects with breaker

